Sine-Wave Locomotion in a Robotic Snake Model Form and Programming

Mark W. Sherman

Tennyson High School 20375 Whitman Street Hayward, CA 94544 arctangent@hotmail.com

Abstract

Mathematical phenomena displayed by biological life can be useful considerations when trying to reproduce aesthetically pleasing patterns of locomotion. Specific to this project was the study, design and construction of a robotic snake while trying to preserve the mechanism of movement that allows the biological snake to move along a selected path. Mathematical expressions for the serpentine movement of a living snake clarified and formed the basis for the translation from biological to robot. With the addition of sensory abilities, the robot can interact with its environment, and finally a user interface allows interaction with the robot.

1 Introduction

The purpose of this project was to mimic the locomotive movements achieved by biological snakes. Snake locomotion is very intriguing because it does not require the use of limbs such as legs or arms to move. Although many robots use wheels for locomotion, they usually become caught on obstacles or find areas inaccessible due to their size. To eliminate the use of wheels that limit the terrain able to be covered, some robots have attempted to mimic the walking motion of animals. Walking robots

can range from very simple, to very complex, but often have trouble with balance or obstacles, and their movements are not usually smooth. The wave-like motion of a snake is promising for robotic development because it allows smoother locomotion. The beneficial aspect of such a robot could include carrying hazardous materials, inspection in uncertain terrain such as the debris of a downed building after an earthquake, or assisting law enforcement personnel in surveillance maneuvers.

This paper will cover the concept, design, construction and programming considerations which governed the successful execution of this project. Included are appropriate schematic diagrams and examples of programming, a discussion of the mathematical principles which generated the sine wave locomotion, as well as

specific construction techniques developed to complete this project.

2 Related Work

As part of the research phase, an understanding into the mechanism of movement utilized by a biological snake was imperative. It is quickly obvious upon studying biological snakes that they have a series of scales along their bellies, called scutes, which perform the function of side-to-side resistance (traction) that helps the snake pull its body along. In fact, research into experiments conducted by biologists found that without this form of traction, the serpentine movement of the snake does not take place. For instance, the bad traction obtained by a snake on loose sand, will cause a side-winding trajectory rather than a forward path. For this reason, not all snakes utilize the lateral undulation method of locomotion, but rather, there are four patterns of locomotion employed by biological snakes.² For the purposes of this project, the mathematical model is the sine wave, and so locomotion by lateral undulation is the most appropriate description of the project goal.


The fact that biological snakes rely on traction on the ground to be able to move forward forms the basis for the ideals which governed the design and component placement on the robot.³ There is also a growing group of biological scientists who see robotic "specimens" as a way to test hypotheses in the laboratory without harm to a natural environment or wildlife.⁴ Robotic medical instruments in the form of robotic snakes are already under development to aid doctors in the collection of data, images and tissue samples from patients' bodies with increasing precision.^{5/6} Robotic snakes have numerous applications within several fields of study.

3 Mechanical Design

3.1 Purposeful Design

Since one of the goals of this project was to make the robotic snake in the likeness of a biological snake, it was decided that the "brain" should be at the head end of the robot. Further, a definite underbelly and tail section are also present. The brain connects to the servos, the

Snake Microcontroller Board



Schematic Diagram: Snake Microcontroller

muscles of the robot, through a spinal column of appropriately sized ribbon cable passed through a 1/2" hole drilled into each segment support. This approximates the neural distribution or signal delivery to each servo (muscle) required for the sine wave technique.

4 Construction

There are several important issues regarding the construction of the robot including cost versus available budget for the project, arriving at adequate construction methods without sacrificing performance, the impact upon performance after material selection and, finally, unique construction methods used in this particular robot.

4.1 Budget

The problems encountered trying to conduct research without adequate funding certainly plagued this project.

This, in fact, caused potential shelving of the project at several points. In the end, a balance between function and practicality surfaced. While it is too early to determine that this had a significant impact upon the results of this research, it can be determined that considerable robotics research can be conducted despite fiscal obstacles.

Through the careful evaluation of a component's desirability when considered within the given the budget constraints, components were obtained from scrap yards, surplus electronic supply outlets, company discards and sample components obtained at trade shows. Absent a benefactor, this was the only way to continue this project. The possibility of negating progress due to budgetary constraints was a constant problem. Limits placed upon functionality became possibilities that needed to be addressed so that the integrity of the effort was not jeopardized.

4.2 Design

4.2.1 Biological vs. Mechanical

Upon researching biological snakes, segmentation of the body seemed the natural mode of representation. In order to achieve the multiple angles required for locomotion, the robotic snake needed to have segments articulated by servos. The segments are a mechanical "rib" system, and the hobby-grade servos operate as the "muscle" of the snake. A single degree of freedom for each segment is represented in this project with further development planned to include increasing degrees of freedom.

4.2.2 Weight and Tension Supports

Each aluminum section of the body support was logically made identical to the others in size and shape. This ensured proper fit with each servo as well as maximized the possibility that if one segment appropriately touched the floor, all others should, in theory, do the same. The materials chosen had to be lightweight enough to conserve energy, yet sturdy enough to support both the servo mounted on it, and still withstand the strains of other segments' movements. The "spine" of the snake needed to be robust enough to hold its own weight, accept opposing influence from other segments, and do so while in continuous motion.

An "S" curve was first fashioned out of stiff cardboard and later adopted as the design shape of the segment supports. Using 1/16" sheet aluminum scrap, ten identical segments were fashioned in this "S" form. (See **Diagram** 1 below.) Half-inch holes were punched into one slope end of the "S" shape in order for the necessary wires to pass through. This, in effect, constituted a "spinal column" that connected the servos to the "brain." The "S" design allows each servo to securely attach to the segment in front and behind without causing interference with the degree of turn obtainable from each servo. Each of nine segments has a servo attached via the "control horn" provided by the manufacturer, while the head end carries the "brain" in the form of a circuit board.

4.2.3 Traction

Although ideally the robot should eventually maneuver without wheels, its current design utilizes wheels as traction devices in the locomotive process. Wheels that can only roll forward and back while providing side-to-side resistance (traction) appear on the underside of each segment. The position was determined by estimating the center of gravity on each segment in an effort to maximize the traction mentioned above. Surplus Lego® wheels were chosen, for their low cost, availability and their consistent quality. It was possible to give each segment a wheel assembly identical in function as all other segments, an important consideration in the sine wave technique which works best when all pivot points are equal.

4.2.4 Power

Four "AA" Nickel Metal Hydride (NiMH) batteries were distributed on four sections to supply power to the servos. These were placed on the front half of the snake. Ribbon wire was strung through section to connect the servos to the microcontroller brain.

Separate power for the microcontroller was provided by a 9 V NiMH battery. The Basic-X controller has an onboard 5 V regulator which made using a 9 V battery practical and economical, since it was a regular stock item.

The separation of power sources for the servos and the microcontroller prevents the microcontroller from resetting when the servos pulse on. Testing revealed that having shared power source caused a voltage drop high enough to reset the microprocessor. Further, using separate switches to control the power, allows programming to occur on the Basic-X without the servos running.

Each servo takes about 120 mA average current when on, and about 1 Amp when all nine servos are running. The "AA" NiMH cells have an approximate capacity of 1600 mA/hr. This translates into roughly 1 1/2 hours run time.




Diagram 1: Snake Segment

4.2.5 Microcontroller Assembly

The Basic-X module was mounted in a 24 pin socket on a Radio Shack #276-150 perf board trimmed to the dimensions: 2 3/8" x 1 7/8", then attached to the head end of the snake. Power switches for servos and the Basic-X were mounted on the same segment.

Access to all 16 ports of the Basic-X was achieved using female headers on the board. Each port made available power and common so each servo could directly connect to the Basic-X. A 750 ohm series resistor on each port connection to the Basic-X provided protection against any direct shorts due to wiring errors. A 3300 uF capacitor was connected across the servo power supply to help smooth out surges caused by the servos powering on.

Seven of the sixteen ports provide 5 volts (from the Basic-X regulator) and common connection to external sensors, switches, or other devices. The remaining nine ports supplied separate power to the servos from the four NiMH "AA" cells.

Connection to the computer's serial com port through a male header on the circuit board made quick and easy changing of the program without the necessity of removing the microprocessor from the robot. When power switches are off, the batteries can be checked and charged easily through a cable connecting to a male header mounted on the control circuit board.

5 Theory of Operation

During locomotion, the servos move in the pattern close to a sine wave. The underside of the robot has wheels, which have little friction forward and back, but much more friction from left to right. As the segments move in a sine pattern, the robot is forced to move forward, since each segment can only move forward or backward. The wheels resist side to side motion. Unlike a biological snake which cannot slither in reverse, our robot achieves backwards locomotion by reversing the direction of the wave. Turning left or right is accomplished by adding a curve to the sine, producing a sine wave that curves in one direction.

5.1 Sine Wave Controls Servo Angle

In the program, the subroutine which controls servo movement, takes an operand from 0 to 1 indicating servo angle. The servos have approximately 180° degrees of movement. To produce a smooth oscillating pattern for a single servo, the equation $y=(\sin(x)/4.0)+.5$ is used. As x is incremented, the servo angle will smoothly increase and decrease repeatedly.

5.2 Phase Shift

For the robot to move effectively, all the servos must move together to produce a pattern. If an image of the snake were taken as it was moving, the snake would have a sine-looking pattern to it. This is accomplished by adding a phase shift to each servo segment. This results in each servo behind the head moving 0.8 radians out of phase with the servo in front of it. This is accomplished by the following code:

```
For segment = 1 to 9 
y=( \sin (x - 0.8 * csng(segment) ) /4.0 + 0.5 
MoveServo segment + 11, y + toff*csng( 10-segment) 
Next
```

The division by 4 scales the amplitude of the sine down to 25%, and the addition of 0.5 makes 0.5 the center location instead of 0. The MoveServo subroutine takes the pin# of the microprocessor the the servo is connected to as the first argument, and then angle as the second. The y value calculated before is added to an offset (toff) value multiplied by the segment number. This allows the robot to turn.

5.3 Making a Turn

If x were graphed against the turning offset (toff* 10segment), it would be a line. How does adding a line make the robot curve in one direction? It does because these y values are not the y values you would expect on a cartesian x-y plane. The y values are actually angles. So if toff was .05, the first servo turns an angle of 0.05, the second turn 0.10, and the third 0.15. Assume the head of the snake were at a fixed angle and position. The actual angles positions observed for each segment would be the sum of that segment and all the servo angles for the segments before it. So, the first segment would have an angle of 0.05, the second would have (0.05+0.10)=0.15, and the third would have (0.05+0.10+0.15)=.30. The curve's angles are added to the sine angles calculated earlier. When the snake is turning, toff is either positive and negative. This changes the sine wave pattern of the robot to a curved sine.

5.4 Program


Below is the program used to achieve sine-wave locomotion with the snake model described:

'Robotic Snake Model Controller Program for Basic X 'Written in Visual Basic 'Mark W. Sherman

dim mode as byte 'snake mode 0=stop 1=forward
'2=left 3=right 4=backward
dim xinc as single 'x increment
dim toff as single 'turning offset (for turns)
dim speed as single 'snake speed
Sub Main()
dim segment as byte 'snake segment counter
dim x as single 'x coordinate independent
'variable
dim y as single 'y coordinate dependant variable

dim countdown as byte 'time delay counter speed=0.3 'set a medium speed

putpin 25.0 delay 0.5 putpin 25.1 putpin 25.1 putpin 25.0 delay 0.5 putpin 25.1 putpin 25.0 delay 0.5 putpin 25.1 ly second delay delay 0.5 putpin 25.1 ly second delay delay 0.5 putpin 25.1 ly second delay delay 0.5 ly 1/2 second 0.5 ly 1/2 secon	'Flash colored lights	delay 0.25
putpin 25.1 putpin 25.0 delay 0.5 putpin 25.1 delay 0.5 putpin 25.1 delay 0.5 '1/2 second delay (1.5 of the putpin 25.1) delay 0.5 '1/2 second delay (1.5 of the putpin 25.1 delay 0.5 '1/2 second delay (1.5 of the putpin 25.1 delay 0.5 '1/2 second delay (1.5 of the putpin 25.1 delay 0.5 of the putpin 25.1 delay 0.5 '1/2 second delay (1.5 of the putpin 25.1 delay 0.5 of the putpin 25.0 'to delay 0.5 of the putpin 25.0 'blink red & green lights to indicate putpin		•
putpin 26.0 delay 0.5 putpin 25.1 delay 0.5 putpin 25.1 delay 0.5 yil/2 second delay 0.5 yil/2	delay 0.5	end if
delay 0.5 putpin 25,1 delay 0.5 '1/2 second delay x=0.0 'set wave to initial position toff=0.00 'range :>0.2 ro +0.2: 0.0 is straight, - is iright, + is left xinc=0.0 mode=0 'start robot in a stopped state countdown=0 'no countdown=0 'no countdown of countdown=0 'no countdown=0 'no countdown of if (countdown=0) then countdown = 0 end if if countdown=1 then mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=xnic '.reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'louched mode=2 'left countdown=30 '30 cycles moving to 'the left call updatemode() 'xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving to real updatemode() 'in fire delay 0.25 call updatemode() 'in fire speed = 0.1 end if delay 0.25 call updatemode() end if if getpin(1)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if geed=0.0 end if if getpin(1)=0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception' putpin 26,0 mode=mode=1 'increment to the next mode if mode=4 then 'varpa around if necessary mode=0 end if		for segment = 1 to 9 'for each of the nine segments
segment) delay 0.5 '1/2 second delay x=0.0 'set wave to initial position toff=0.00 'range : .02 ro + .02: 0.0 is straight, - is fright, + is left xinc=0.0 mode=0' start robot in a stopped state countdown=0 'no countdown do countdown=0 'no countdown (if (countdown=0) then countdown=0 then mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left xinc=xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to the left call updatemode() xinc=xinc 'reverse robots direction end if if getpin(0)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving in the reverse dir call updatemode() xinc=xinc 'reverse robots direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=0.1 end if delay 0.25 call updatemode() and if if getpin(1) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'freeption mode=0 't increment to the next mode if mode=0 't hen 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'freeption mode=0 't increment to the next mode if mode=0 't hen 'ir in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'freeption mode=0 't increment to the next mode if mode=0 't hen 'vap around if necessary mode=0 end if delay 0.25 call updatemode() 'imove to servo to to that angle + and turning offset next Delay 0.020 'delay 1/50 second x=+xine 'range: -0.4 to +0.4: 0.0 is stop, + is 'loward, : is backwards 'move to serve to that angle + and turning offset next Delay 0.020 'delay 1/50 second x=+xine 'range: -0.4 to +0.4: 0.0 is stop, + is 'loward, : is backwards 'fir x < 6.28 then x=-6.28 end if if set angle if x > 6.28 then x=-6.28 end if if mode=0 then 'stop xinc=-0.0 toff=0.0 if mode=0 then 'loward xinc=speed toff=0.0 xinc=speed end if if mode=2 then 'left toff=0.04 xinc=speed end if if		
delay 0.5 '!12 second delay x=0.0 'set wave to initial position toff=0.00 'range :>0.2 ro +02: 0.0 is straight, - is 'right, + is left xinc=0.0 mod=0 'start robot in a stopped state countdown=0'no countdown=0 or countdown=0'no countdown=0 end if if countdown=1 then mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left 'in the countdown = 15 the left call updatemode() 'update movement variables end if if getpin(10)=0 then 'if the left touch sensor is touched mode= 2 'left countdown=30 '30 cycles moving to 'the left call updatemode() xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving to 'the left call updatemode() xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the speed select key is pressed speed=speed+0-1 'increment robot's speed if speed>0.1 end if 'if mode=2 then 'right toff=0.0 xinc=speed end if if edday 0.25 call updatemode() if getpin(1)=0 then 'if the speed select key is pressed speed=speed+0-1 'increment robot's speed if speed>0.1 end if 'if mode=3 then 'right toff=0.0 xinc=speed end if if edday 0.25 call updatemode() if getpin(1)=0 then 'if in infrared signal is pressed putpin 25.0 'blink red & green lights to indicate 'reception putpin 26.0 mode=1 'increment to the next mode if mode>4 then 'wrap around if necessary mode=0 end if	•	
x=0.0 set wave to initial position toff=0.00 signage : .02 ro + .02: 0.0 is straight, - is right, + is left since=0.0 mode=0 start robot in a stopped state countdown=0 no countdown=0 no countdown=0 start robot in a stopped state countdown=0 store of (countdown=0) then countdown=1 stern when there are 15 cycles left if countdown=1 stern when there are 15 cycles left sife countdown=15 then when there are 15 cycles left sife countdown=15 then when there are 15 cycles left sife countdown=15 then when there are 15 cycles left sife stouched mode=2 sleft countdown=30 30 cycles moving to the left call updatemode() simply of the sife store of the store of		c /
toff=0.00 'range: -02 ro +.02: 0.0 is straight, - is		
"right, + is left xinc=0.0 mode=0 'start robot in a stopped state countdown=0 'no countdown do countdown=0 'the countdown=0 'the countdown=1 'deincrement countdown if (countdown=0) then countdown=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=1 5 then 'when there are 15 cycles left 'in the countdown xinc=xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to 'the left call updatemode() 'xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving in the reverse dire call updatemode() 'xinc=xinc 'reverse robot's direction end if if getpin(5)=0 then 'iff the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed=0.1 end if delay 0.25 call updatemode() end if getpin(1) = 0 then 'iff in infrared signal is pressed putpin 25.0 'blink red & green lights to indicate 'reception putpin 26.0 mode=mode+1 'increment to the next mode if mode=2 4 then 'tincrement to the next mode if mode=2 4 then 'tincrement to the next mode if mode=4 then 'warp around if necessary mode=0 end if 'cenerate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
xinc=0.0 mode=0 'start robot in a stopped state countdown=0 'no countdown do countdown=countdown-1 'deincrement countdown if (countdown=0) then countdown=0 then mode=1 set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left	E ,	
mode=0 'start robot in a stopped state countdown=0 'no countdown-1 'deincrement countdown if (countdown=0) then countdown=1 'deincrement countdown if (countdown=0) then countdown=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=1 then mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left 'in the countdown 'xinc=-xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to 'the left call updatemode() 'xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving in the reverse dir call updatemode() 'xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'iff the speed select key is pressed speed=9.01 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'iff in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'warp around if necessary mode=0 end if 'in femelate 1.5 ms. PulseWidth 8.0 xls file of 28 then x=x+6.28 end if if x > 6.28 then x=x+6.28 end if if x > 6.28 then x=x+6.28 end if if sx > 6.28 then x=x+6.28 end if if mode=0 then 'stop xinc=0.0 to file if if mode=0 then 'stop xinc=0.0 to file if mode=0 then 'stop xinc=0.0 to file if mode=0 then 'stop xinc=0.0 to file if mode=2 then 'left to file observed to file if mode=2 then 'left to file if mode=3 then 'right to file if mode=4 then 'backward to file=0.04 xinc=speed end if	G ,	
countdown=0 'no countdown do countdown countdown-1 'deincrement countdown if (countdown=0) then countdown=0 end if if countdown=1 then mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=xinc 'reverse the direction of the robot's motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to 'the left call updatemode() xinc=xinc 'reverse robot's direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving in the reverse dir call updatemode() xinc=xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1' increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25.0 'blink red & green lights to indicate 'reception putpin 26.0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Enabled and if 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Enabled and if 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Enabled and if 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Enabled and sub-servo pin. Call PulseVouth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseVouth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseVouth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseVouth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseVouth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseVouth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseVouth = 0.00		
countdown=countdown-1 'deincrement countdown if (countdown=0) then countdown=0 end if if countdown=1 hen mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=-xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to the left call updatemode() xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30'30 cycles moving in the reverse direall updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Enable Cut(ServoPin, PulseWidth - 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseCut(ServoPin, PulseWidth, 1) End Sub		
countdown=countdown-1 'deincrement countdown if (countdown=0) then countdown=0 end if if countdown=1 then mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to 'the left call updatemode() xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving to rall updatemode() xinc=xinc 'reverse robots' direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed=0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if end if the speed select with the next mode if mode > 4 then 'wrap around if necessary mode=0 end if end if the speed select if speed > 0.0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 'mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'the speed select was pressed a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) end sub 'if countdown=1 then 'if one mat if if countdown=1 then 'forward xinc=speed end if if if mode=2 then 'left toff=0.0 a xinc=speed end if if if mode=2 then 'left toff=0.0 a xinc=speed end if if mode=4 then 'backward toff=0.0 a xinc=speed end if if mode=4 then 'backward toff=0.0 a xinc=speed end if if mode=4 then 'backward toff=0.0 a xinc=speed end if if mode=4 then 'backward toff=0.0 a xinc=speed end if if mode=4 then 'backward toff=0.0 a xinc=speed end if if mode=4 then 'backward tof		
if (countdown=0) then countdown = 0		
countdown = 0 end if if countdown=1 then mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=-xinc 'reverse the direction of the robot's motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to 'the left' call updatemode() xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed>0.6 then 'and wrap around if too high speed= 0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'End Sub		
end if if countdown=1 then mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=-xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to 'the left call updatemode() xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30'30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is presed speed=9.1 end if 'if getpin(11)=0 then 'if in infarred signal is presed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 'blink red & gree		
if countdown=1 then mode=1 'set mode to forward call updatemode() 'update movement variables end if' if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=xinc 'reverse the direction of the robot's 'motion end if' if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to 'the left' call updatemode() xinc=xinc 'reverse robots direction end if' if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving in the reverse dir call updatemode() xinc=xinc 'reverse robot's direction end if' if getpin(5)=0 then 'if the speed select key is pressed speed=9.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if' delay 0.25 call updatemode() end if' if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if' Ison de=0 then 'stop xinc=0.0 toff=0.0 end if' if mode=2 then 'left toff=0.0 * xinc=speed end if' if mode=2 then 'left toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=2 then 'left toff=0.0 * xinc=speed end if' if mode=2 then 'left toff=0.0 * xinc=speed end if' if mode=2 then 'left toff=0.0 * xinc=speed end if' if mode=2 then 'left toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if mode=4 then 'backward toff=0.0 * xinc=speed end if' if m		
mode=1 'set mode to forward call updatemode() 'update movement variables end if if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=-xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to 'the left call updatemode() xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30'30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if End Śub Sub updatemode() if mode=0 then 'stop xinc=0.0 end if if mode=1 then 'forward xinc=speed toff=0.0 end if if mode=2 then 'left toff=0.0 xinc=speed end if if mode=3 then 'right toff=0.04 xinc=speed end if if mode=4 then 'backward toff=0.0 xinc=speed end if if mode=4 then 'backward toff=0.0 xinc=speed end if if mode=4 then 'backward toff=0.0 xinc=speed end if if mode=3 then 'right toff=0.04 xinc=speed end if if mode=2 then 'left toff=0.04 xinc=speed end if if mode=3 then 'right toff=0.04 xinc=speed end if if mode=3 then 'right toff=0.04 xinc=speed end if if mode=4 then 'backward toff=0.0 xinc=speed end if if mode=3 then 'right toff=0.04 xinc=speed end if if mode=4 then 'backward toff=0.0 xinc=speed end if if mode=4 then 'backward toff=0.0 xinc=speed end if if mode=1 then 'forward xinc=speed end if if mode=3 then 'right toff=0.04 xinc=speed end if if mod=3 then 'right toff=0.04 xinc=speed end if if mode=3 then 'ri		
end if if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode= 2 'left countdown =30 '30 cycles moving to 'the left call updatemode() xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode= 3 'right countdown =30 '30 cycles moving in the reverse dir call updatemode() xinc=xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
end if if countdown=15 then 'when there are 15 cycles left 'in the countdown xinc=xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode= 2 'left countdown =30 '30 cycles moving to 'the left call updatemode() xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode= 3 'right countdown =30 '30 cycles moving in the reverse dir call updatemode() xinc=xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Call PulseOut(ServoPin, PulseWidth, 1) End Sub	call updatemode() 'update movement variables	
in the countdown xinc=xinc 'reverse the direction of the robot's 'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode= 2 'left countdown =30 '30 cycles moving to 'the left call updatemode() xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode= 3 'right countdown =30 '30 cycles moving in the reverse dir call updatemode() xinc=xinc 'reverse robots' direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed= 0.1 end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		Sub updatemode()
xinc=-xinc 'reverse the direction of the robot's motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown=30 '30 cycles moving to the left call updatemode() xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(9)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if if mode=1 then 'forward xinc=speed toff=0.0 end if if mode=2 then 'left toff=0.04 xinc=-speed end if if mode=3 'hen 'right toff=0.04 xinc=-speed end if if mode=3 'hen 'right toff=0.04 xinc=-speed end if if mode=4 then 'backward toff=0.00 xinc=-speed end if end sub Public Sub MoveServo(ByVal ServoPin As Byte, _ ByVal Position As Single) 'Basic X Servo Routine ' Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub	if countdown=15 then 'when there are 15 cycles left	if mode=0 then 'stop
'motion end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode=2 'left countdown =30 '30 eycles moving to 'the left call updatemode() xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown =30 '30 eycles moving in the reverse dir call updatemode() xinc=xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode>4 then 'backward toff=0.0 xinc=-speed end if end sub speed=0.1 end if Public Sub MoveServo(ByVal ServoPin As Byte, _ ByVal Position As Single) 'Basic X Servo Routine 'Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub	'in the countdown	xinc=0.0
end if if getpin(10)=0 then 'if the right nump sensor is 'touched mode= 2 'left countdown =30 '30 cycles moving to 'the left call updatemode() xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode= 3 'right countdown =30 '30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode> 4 then 'wrap around if necessary mode=0 end if end sub served if speed > 4 then 'wrap around if necessary mode=0 end if end sub serve pin. Call PulseOut(ServoPin, PulseWidth, 1) end if end sub	xinc=-xinc 'reverse the direction of the robot's	toff=0.0
if getpin(10)=0 then 'if the right nump sensor is 'touched mode= 2 'left countdown =30 '30 cycles moving to 'the left call updatemode() xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode= 3 'right countdown =30 '30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed = 0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if if getpin(10)=0 then 'if the right nump sensor is touched toff=0.0 end if if mode=2 then 'left toff=0.04 xinc=speed end if if mode=3 then 'right toff=-0.04 xinc=speed end if if mode=4 then 'backward toff=0.0 xinc=-speed end if if mode=2 then 'left toff=0.04 xinc=speed end if if mode=4 then 'backward toff=0.04 xinc=speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yield = 0.00 if mode=0 to 1 increment robot's speed end if if mode=4 then 'backward toff=0.0 yie	'motion	
'touched mode= 2 'left countdown =30 '30 cycles moving to 'the left call updatemode() xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode= 3 'right countdown =30 '30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed= 0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if end if Conde=2 then 'left toff=-0.04 xinc=speed end if if if mode=3 then 'right toff=-0.04 xinc=speed end if if mode=4 then 'backward toff=-0.00 xinc=-speed end if end sub speed= on if end sub speed= on if if mode=4 then 'backward toff=-0.04 xinc=speed end if if end sub sinc=speed= end if end if if mode=4 then 'backward toff=-0.04 xinc=speed= end if if mode=4 then 'backward toff=-0.04 xinc=speed= end if if winc=speed= on if if end sub sub speed= on if if end sub sub speed= on if if end sub sub speed= on if if end sub sub sub speed= on if if end sub		
mode= 2 'left countdown = 30 '30 cycles moving to		
'the left call updatemode() xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode= 3 'right countdown = 30 '30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed= 0.1 end if delay 0.25 call updatemode() end if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate		
call updatemode() xinc=xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown =30 '30 cycles moving in the reverse dir call updatemode() xinc=xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate		
xinc=-xinc 'reverse robots direction end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30 '30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if if mode=3 then 'right toff=-0.04 xinc=-speed end if if mode=4 then 'backward toff=0.0 xinc=-speed end if end sub xinc=speed end if toff=-0.04 xinc=speed end if toff=-0.04 xinc=speed end if toff=-0.04 xinc=speed end if if mode=3 then 'right toff=-0.04 xinc=speed end if toff=-0.04 xinc=speed end if if mode=3 then 'right toff=-0.04 xinc=speed end if if mode=3 then 'right toff=-0.04 xinc=speed end if if mode=3 then 'right toff=-0.04 xinc=speed end if if mode=4 then 'backward toff=-0.0 xinc=-speed end if if mode=4 then 'backward toff=-0.0 Dim Sub Sub MoveServo(ByVal ServoPin As Byte, _ ByVal Position As Single) 'Basic X Servo Routine 'Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
end if if getpin(9)=0 then 'if the left touch sensor is touched mode=3 'right countdown=30'30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 "blink red & green lights to indicate	• •	
if getpin(9)=0 then 'if the left touch sensor is touched mode= 3 'right countdown = 30 '30 cycles moving in the reverse dir call updatemode() if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed end if speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if end sub if getpin(11) = 0 then 'if in infrared signal is pressed putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if end sub if mode=3 then 'right to toff=-0.04 xinc=speed end if end sif mode=3 then 'right toff=-0.04 xinc=speed end if public Sub MoveServo(ByVal ServoPin As Byte, ByVal Position As Single) 'Basic X Servo Routine or 'Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
mode= 3 'right countdown = 30 '30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed= 0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if toff=-0.04 xinc=speed end if if mode=4 then 'backward toff=-0.0 xinc=-speed end if Public Sub MoveServo(ByVal ServoPin As Byte, — ByVal Position As Single) 'Basic X Servo Routine ' Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, ' centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
countdown =30 '30 cycles moving in the reverse dir call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed speed > 0.6 then 'and wrap around if too high speed=0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if xinc=speed end if if mode=4 then 'backward toff=0.0 xinc=-speed end if end sub Public Sub MoveServo(ByVal ServoPin As Byte, _ ByVal Position As Single) 'Basic X Servo Routine ' Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, ' centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub	- - · · ·	_
call updatemode() xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed = 0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'backward toff=0.0 xinc=-speed end if end sub Public Sub MoveServo(ByVal ServoPin As Byte, _ ByVal Position As Single) 'Basic X Servo Routine ' Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, ' centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
xinc=-xinc 'reverse robot's direction end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed= 0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'backward toff=0.0 xinc=-speed end if end sub Public Sub MoveServo(ByVal ServoPin As Byte, ByVal Position As Single) 'Basic X Servo Routine ' Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, ' centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
end if if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed= 0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate ' reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if toff=0.0 xinc=-speed end if end sub Public Sub MoveServo(ByVal ServoPin As Byte, _ ByVal Position As Single) 'Basic X Servo Routine ' Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, ' centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
if getpin(5)=0 then 'if the speed select key is pressed speed=speed+0.1 'increment robot's speed end if speed > 0.6 then 'and wrap around if too high speed= 0.1 end if delay 0.25 all updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if speed=speed+0.1 'increment robot's speed end if end sub speed= 0.1 Public Sub MoveServo(ByVal ServoPin As Byte, _ ByVal Position As Single 'Basic X Servo Routine ' Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, ' centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
speed=speed+0.1 'increment robot's speed if speed > 0.6 then 'and wrap around if too high speed= 0.1 end if delay 0.25 eall updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if speed=0.1 end if end sub Public Sub MoveServo(ByVal ServoPin As Byte, _ ByVal Position As Single 'Basic X Servo Routine ' Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, ' centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
speed= 0.1 end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if Public Sub MoveServo(ByVal ServoPin As Byte, ByVal Position As Single) 'Basic X Servo Routine 'Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		•
end if delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if Public Sub MoveServo(ByVal ServoPin As Byte, ByVal Position As Single) 'Basic X Servo Routine 'Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub	if speed > 0.6 then 'and wrap around if too high	end sub
delay 0.25 call updatemode() end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate ' reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if ByVal Position As Single) 'Basic X Servo Routine ' Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, ' centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
call updatemode() end if end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Moves a servo by sending a single pulse. The position is 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
end if if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'a nondimensional value in range 0.0 to 1.0. Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
if getpin(11) = 0 then 'if in infrared signal is pressed putpin 25,0 'blink red & green lights to indicate 'reception 'to 2.0 ms, putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if Dim PulseWidth As Single 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
putpin 25,0 'blink red & green lights to indicate 'reception 'to 2.0 ms, putpin 26,0 'centered at 1.5 ms. mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'Translate position to pulse width. Resulting range is 1.0 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
'reception 'to 2.0 ms, putpin 26,0 mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if 'to 2.0 ms, 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
putpin 26,0 'centered at 1.5 ms. mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 call PulseOut(ServoPin, PulseWidth, 1) end if 'centered at 1.5 ms. PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
mode=mode+1 'increment to the next mode if mode > 4 then 'wrap around if necessary mode=0 end if PulseWidth = 0.001 + (0.001 * Position) 'Generate a high-going pulse on the servo pin. Call PulseOut(ServoPin, PulseWidth, 1) End Sub		
if mode > 4 then 'wrap around if necessary mode=0		
mode=0 Call PulseOut(ServoPin, PulseWidth, 1) end if End Sub		
end if End Sub	*	
		Dire Cat



Schematic 2: Infrared Remote Control (IRC)

6 User Interface

6.1 Infrared Remote Control (IRC)

The robot is controlled more directly by the user through the use of the project-designed IRC. The infrared signals are picked up by the onboard infrared receiver contained on the main "brain" circuit board. If the robot receives a signal from the remote control, it will cycle through various modes of operation with each press: forward, left, right, reverse, and frozen. The command hierarchy programmed into the robot uses stop as the default, and on subsequent signals, begins to cycle through the above list of simple commands. The whisker sensors have the highest priority. This position in the hierarchy will circumvent the remote control signals if the user tries to command the robot to run into an obstacle.

6.2 Necessary Interpretations/Assumptions

It is necessary to assume that the user, at this stage of project development, is an integral part of the experiment. Therefore, user interface is provided by the use of the IRC.

6.3 Construction

The IRC is housed inside a plastic project box obtained as a trade show sample. The box measures $4\ 1/8$ " x $2\ 3/8$ " x 13/16" and houses the circuit board and also a $9\ V$ NiMH battery as a power source. Activation is via pushbutton control by the user. See **Schematic 2**, "High Power IR Remote" above.

6.4 Program

Following is the program used in the infrared transmitting device. While an ordinary 38 khz TV remote control works, part of this project was to design all components possible for the project.

'Program written using Pic Basic Pro from

'Micro Engineering Labs

define osc 20 trisa=%1111101

trisb=%1111110

n var byte

func var byte

push var portb.2

detect: 'determine mode read 1,func 'read eeprom

if (func<>0) and (func <> 1) then func=1

write 1,func

if push = 0 then func = func xor 1

write 1,func endif

indicate: 'indicate mode to user high porta.1 'ON indicator led goes high

if func = 0 then goto cont if func = 1 then goto pulseme

pulseme:

for n= 1 to 250 'start burst of 38 kc

high portb.0 'led ON

pauseus 5 'led ON for 5 usec

low portb.0 'led OFF

pauseus 17

asm 'fine tune delay

nop nop nop nop endasm

next n 'repeat to complete burst

delay: low porta.1

pause 400 'delay and do another burst

goto indicate

cont: 'routine for continuous burst

for n= 1 to 250 'start burst

high portb.0 'led on

pauseus 5 'led ON for 5 more usec

low portb.0 'led OFF
pauseus 17 'off time for led
asm 'fine tune delay

nop nop nop nop endasm next n

goto cont 'continue burst flip1: write 1,1 'write a 1 to address 1

return end

7 Preliminary Results

Under remote control, the snake robot was able to move forward, reverse, and move to the left or right. After adding two touch sensors to the front of the robot, a little bit of autonomy was achieved. When the robot makes contact with an obstacle, it backs up and turns away from it. It then continues forward.

When the user sets a mode from remote control, (such as forward, turn, etc.) the robot will obey unless it receives

touch sensor input. The user cannot force the robot to move into an obstacle.

Even with simple obstacle detection, the robot can often get in to trouble. If it gets trapped in a corner, it will repeatedly turn left and right until it is rescued. There is also no way to detect obstacles it touches as it backs up. In the future, use of infrared for obstacle detection and having the ability to sense obstacles all around are desirable additions.

8 Conclusions and Future Work

In this paper, we have pointed out that robotic research can be done within limited budgets and still achieve some degree of success. We have also discussed the advantages to using mathematical phenomena found in biological species to create an aesthetically pleasing locomotion pattern in a robotic machine.

Design changes will take place to incorporate additional degrees of freedom. This will enable the snake to maneuver over uneven terrain, which will bring this project one step closer to achieving one of the project goals: designing a robot that could assist in surveillance maneuvers over terrain with debris in the path. Plans to provide additional sensory capacity for heat, light and motion are under development, as well as the delivery to a remote location of audio/visual capacity so information can be sent back to the user remotely. Experiments into finding materials suitable to achieve the traction goals of the original wheels used, will be conducted to eliminate the use of the wheel as a traction device. There is also the evolution of intelligence to make the snake more independent of the user. Last, but always important, new ways to fund robotic research and encourage more high school and college students to prepare for robotics related occupations needs to receive significant attention.

References

¹Docent 2001 Snake Facts: Snakes of Indiana Homepage http://herps.ipfw.edu/center/accounts/snakes/INSnakes.htm ²Vertebrate Natural History 2001: Vertebrate Locomotion http://muskingum.edu/~ingold/lectures/232lec10.htm ³Owen, Scott 1997. The Motion Dynamics of Snakes and Worms

http://www.css.tayloru.edu/instrmat/graphics/hypgraph/animation/art_life/snakes.htm

⁴Current Opinion in Neurobiology 8:777-782 http://vorlon.cwru.edu/~beer/Papers/BioRobotics.pdf ⁵Chen 1996 Snake-like Robot Endoscopes http://robby.caltech.edu/~chen/res-medical.html ⁶Murray 2000. Geometric Phases, Control Theory, and Robotics. pp 33-34. National Academy Press. http://books.nap.edu/books/030905785X/html/ 34.html#pagetop

Copyright ©2002, American Association for Artificial Intelligence (www.aaai.org). All rights reserved.